



Strapping two trekking poles together

Requires two adjustable trekking poles and a 65cm strap with two buckles at both ends (this strap is supplied with the tipi). This method works with most trekking poles. It is important that they are adjustable to fit the height of the tipi.



Cross the two poles, and pass one of the loops in one of the two points



Wind the strap at the crossing of the two poles. Do as many laps as possible.



Pass the loop in the second tip. Push the poles in the opposite direction, evenly spread the laps



Place one of the two ends on the floor and press down firmly to tighten.

Then adjust the height with one of the poles: it's ready!



The pressure of the tipi on the poles will tighten all the more. To loosen, just pull the other way.

Baskets:

The presence of baskets is not necessary to hold the strap. Small baskets are not a problem, but snow baskets are not recommended because they will induce an angle in the assembly and impair the strength of it.

Resistance:

Adjustable ultra-light trekking poles will be sufficient in quiet situations. In strong winds, it is preferable to use resistant sticks that will remain rigid and improve the tipi's behavior against wind gusts.